

6. Transfer Drive Gear

A: NOTE

For removal, installation and inspection, refer to
“6MT (TY85)” or “6MT (TY75)” section.

6MT (TY85) model:

<Ref. to 6MT(TY85)-52, Transfer Drive Gear.>

6MT (TY75) model:

<Ref. to 6MT(TY75)-62, Transfer Drive Gear.>