

10.Center Differential

A: NOTE

For removal, installation and inspection, refer to
“6MT (TY85)” and “6MT (TY75)” sections.

6MT (TY85) model:

<Ref. to 6MT(TY85)-56, Center Differential.>

6MT (TY75) model:

<Ref. to 6MT(TY75)-69, Center Differential.>