

8. Inspection Mode

A: PROCEDURE

- 1) Start the engine.
- 2) Idle the engine for five seconds or more.
- 3) Operate the steering wheel from side to side.
- 4) Reproduce the malfunction occurrence condition as much as possible.