

11. Neutral Position Switch

A: NOTE

For the operation procedures for neutral position switch, refer to “MANUAL TRANSMISSION AND DIFFERENTIAL” section.

- Except for STI model: <Ref. to 6MT(TY75)-45, Switches and Harness.>
- STI model: <Ref. to 6MT(TY85)-41, Neutral Position Switch.>