

## 5. Clearance Light and Illumination Light System

### A: WIRING DIAGRAM

Refer to "Clearance Light and Illumination Light System" in the wiring diagram.

- Gasoline engine model: <Ref. to WI(w/o HEV)-68, WIRING DIAGRAM, Clearance Light and Illumination Light System.>
- HEV model: <Ref. to WI(HEV)-70, WIRING DIAGRAM, Clearance Light and Illumination Light System.>

### B: INSPECTION

#### 1. CHECK LIGHTING SWITCH

Refer to the "INSPECTION" of the "Combination Switch (Light)". <Ref. to LI-24, INSPECTION, Combination Switch (Light).>

### C: NOTE

For operation procedures of each component of the clearance light & illumination light system, refer to the respective sections.

- Combination switch (light): <Ref. to LI-21, Combination Switch (Light).>
- Parking light bulb: <Ref. to LI-49, Clearance/Parking Light Bulb.>
- Front side marker light bulb: <Ref. to LI-51, Front Side Marker Light Bulb.>
- Rear combination light assembly: <Ref. to LI-60, Rear Combination Light Assembly.>
- Tail light/stop light bulb: <Ref. to LI-63, Tail/Stop Light Bulb.>
- Rear side marker light bulb: <Ref. to LI-69, Rear Side Marker Light Bulb.>
- License plate light: <Ref. to LI-74, License Plate Light.>
- Ignition switch illumination: <Ref. to LI-90, Ignition Switch Illumination.>