

## 14. Transmission Gear Oil

### A: INSPECTION

Refer to “6MT” section for transmission gear oil inspection. <Ref. to 6MT-23, INSPECTION, Transmission Gear Oil.>

### B: REPLACEMENT

Refer to “6MT” section for transmission gear oil replacement. <Ref. to 6MT-23, REPLACEMENT, Transmission Gear Oil.>