


# General Description

## COMMUNICATION SYSTEM

### 1. General Description

#### A: COMPONENT



(1) Hi pitch side horn

(2) Lo pitch side horn

(3) Roll connector

(4) Horn switch (driver's airbag module ASSY)

(5) HORN RELAY

#### B: CAUTION

- Before disassembling or reassembling parts, always disconnect the battery ground cable from battery. When replacing the control module and other parts provided with memory functions, record the memory contents before disconnecting the battery ground cable. Otherwise, the memory is cleared.
- Reassemble the parts in the reverse order of disassembly procedure unless otherwise indicated.
- Connect the connectors securely when reassembling.
- After reassembly, make sure that the functional parts operate normally.

#### C: PREPARATION TOOL

##### 1. GENERAL TOOL

TOOL NAME	REMARKS
Circuit tester	Used for measuring resistance and voltage.
TORX® T30	Used for removing/installing driver's airbag module.