



# (8) ECVT コントロール回路





R47 黒								F126								F84								F111							
R90								1 2 3 4 5 6								21 22 23 24 25 26 27 28 29 30 31 32 33 34 35 36								1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16							
1 2								R2 黒								R18															
R3 青								1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22								23 24 25 26 27 28 29 30 31 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48															
1 2 3 4 5 6 7 8								R128 黒																							
28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1				
55	54	53	52	51	50	49	48	47	46	45	44	43	42	41	40	39	38	37	36	35	34	33	32	31	30	29					
83	82	81	80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61	60	59	58	57	56				

TJ18-03B