

1. General Description

A: CAUTION

- Before disassembling or reassembling parts, always disconnect the battery ground cable from battery.
- When replacing the audio, control module and other parts provided with memory functions, record the memory contents before disconnecting the battery ground cable. Otherwise, the memory is cleared.
- Reassemble the parts in the reverse order of disassembly procedure unless otherwise indicated.
- Adjust parts to the given specifications.
- Connect the connectors securely during reassembly.
- After reassembly, make sure functional parts operate smoothly.

B: PREPARATION TOOL

1. GENERAL TOOL

| TOOL NAME | REMARKS |
|---------------------------------------------------------------|--------------------------------------------|
| Circuit Tester | Used for measuring resistance and voltage. |
| Conductive silver composition (DUPONT No. 4817 or equivalent) | Used for repairing antenna wire. |