

7. Rear Entertainment System

A: WIRING DIAGRAM

<Ref. to WI-119, WIRING DIAGRAM, Rear Entertainment System.>

B: INSPECTION

1. CHECK THE DVD-ROM.

Insert a region code 1 DVD-ROM, and check that the display shows images from the DVD when playing back the media.

NOTE:

Region code 1 is a code for North American DVD-ROM discs. DVD-ROMs of different region codes will not be played back.

Standard value: Image from DVD should be displayed.

OK: Normal

NG: If the images from the DVD is not displayed, check whether the DVD-ROM is set in the rear entertainment system, whether the correct side is set, type of the DVD-ROM, the existence of any scratches, etc. If there are no problems on the DVD-ROM, the main body is defective.

NOTE:

The rear entertainment system is not compatible with MP3 files or DVD-Audio.

2. ERROR DISPLAY AND CONTENT

Screen display	Trouble contents
INCORRECT CODE	When an incorrect number is entered.
DISC ERROR	When it is not possible to read the disc due to scratches or insertion upside down.
REGION CODE ERROR	When the region code of the disc does not match (is a region code other than 1)
MECHA ERROR	Replace the rear entertainment system.
NO DISC	The DVD switch was pressed when there was no disc inside.