

8. Clear Memory Mode

A: OPERATION

For details concerning DTC clear operation, refer to “Subaru Select Monitor”. <Ref. to LAN(diag)-21, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>