

Inspection Mode

BRAKE VACUUM CONTROL (BVC) (DIAGNOSTICS)

8. Inspection Mode

A: PROCEDURE

Reproduce the malfunction occurrence condition as possible.

Drive the vehicle at least ten minutes.