


Starter System

WIRING SYSTEM

19.Starter System

A: WIRING DIAGRAM



WI-08088