

5. General Diagnostic Table

A: INSPECTION

Symptom	Possible cause	Corrective action
Brake drag	Parking brake pedal is misadjusted	Adjust
	Parking brake cable does not move	Correct or replace
	Parking brake shoe clearance is maladjusted	Adjust
	Return spring is faulty	Replace
Noise from brake	Return spring is faulty	Replace
	Brake shoe spring fault	Replace

General Diagnostic Table

PARKING BRAKE

POWER ASSISTED SYSTEM (POWER STEERING)

PS

	Page
1. General Description	2
2. Steering Wheel	14
3. Universal Joint	15
4. Tilt Steering Column	17
5. Steering Gearbox	19
6. Pipe Assembly	38
7. Oil Pump	42
8. Reservoir Tank	48
9. Power Steering Fluid	49
10. General Diagnostic Table	50