


## 18. Navigation Switch

### A: REMOVAL

- 1) Disconnect the ground cable from the battery.
- 2) Remove the control panel. <Ref. to ET-9, RE-MOVAL, Control Panel.>
- 3) Remove the screws and then remove the navigation switch.



### B: INSTALLATION

Install in the reverse order of removal.