

### 8. Clear Memory Mode

#### A: OPERATION

For details concerning DTC clear operation, refer to “Subaru Select Monitor”. <Ref. to LAN(diag)-22, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>