



4. Mud Guard

A: REMOVAL

- 1) Remove the wheels.
 - 2) Loosen the clips to remove mud guard.
- Front mud guard



- Rear mud guard



B: INSTALLATION

Install in the reverse order of removal.