

18. Sunroof Glass

A: PROCEDURE

For removal, installation and adjustment of the sunroof glass, refer to the sunroof section.

- Removal <Ref. to SR-5, REMOVAL, Glass Lid.>
- Installation <Ref. to SR-5, INSTALLATION, Glass Lid.>
- Adjustment <Ref. to SR-5, ADJUSTMENT, Glass Lid.>