


4. Electrical Component Location

A: LOCATION










LAN00181

- | | | |
|--|---------------------------------------|--|
| (1) Body integrated unit | (5) A/C control panel | (9) VDCCM&H/U (In engine compartment) |
| (2) Engine control module (ECM) | (6) Transmission control module (TCM) | (10) Odo/trip meter |
| (3) Auto A/C control module | (7) Combination meter | (11) Yaw rate & G sensor |
| (4) Keyless entry control module (Antenna) | (8) Steering angle sensor | (12) Display (navigation monitor or MFD) |

Electrical Component Location

LAN SYSTEM (DIAGNOSTICS)

 LAN00182	 LAN00183
 LAN00184	 LAN00185
 LAN00186	 LAN00368
 LAN00369	