

## **Clear Memory Mode**

TIRE PRESSURE MONITORING SYSTEM (DIAGNOSTICS)

---

### **8. Clear Memory Mode**

#### **A: OPERATION**

For details concerning DTC clear operation, refer to  
“Subaru Select Monitor”. <Ref. to TPM(diag)-7,  
Subaru Select Monitor.>