

## 4. Oil Seal

### A: NOTE

For replacement and inspection, refer to the "5AT" section. <Ref. to 5AT-46, Extension Case Oil Seal.> <Ref. to 5AT-47, Differential Side Retainer Oil Seal.>