


# Electrical Component Location

IMMOBILIZER (DIAGNOSTICS)

## 3. Electrical Component Location

### A: LOCATION



IM-00401

(1) Antenna

(3) Body integrated unit

(4) Transponder

(2) Security indicator light (LED bulb)