

13. Front & Rear Differential Gear Oil

A: INSPECTION

1. FRONT DIFFERENTIAL

Refer to “5AT” section for front differential gear oil inspection. <Ref. to 5AT-31, INSPECTION, Differential Gear Oil.>

2. REAR DIFFERENTIAL

Refer to “DI” section for rear differential gear oil inspection. <Ref. to DI-17, INSPECTION, Differential Gear Oil.>

B: REPLACEMENT

1. FRONT DIFFERENTIAL

Refer to “5AT” section for front differential gear oil replacement. <Ref. to 5AT-31, REPLACEMENT, Differential Gear Oil.>

2. REAR DIFFERENTIAL

Refer to “DI” section for rear differential gear oil replacement. <Ref. to DI-17, REPLACEMENT, Differential Gear Oil.>