

INSTALLATION

1. INSTALL COOLING FAN

- (a) Install the cooling fan with the 2 bolts.

Torque: 5.0 N·m (51 kgf·cm, 44 in·lbf)

- (b) Connect the 2 cooling fan connectors.

2. INSTALL RADIATOR UPPER SUPPORT

- (a) Install the radiator upper support with the 2 bolts.

- (b) w/ Cruise control system:

Install the cruise control actuator with the 3 bolts.

- (c) Install the 2 condenser upper supports with the 2 bolts and nuts.

- (d) Install the center brace with the 2 bolts.

- (e) Install the hood lock with the 3 bolts.

- (f) Install the engine coolant reservoir.

- (g) Install the air cleaner assembly.

3. INSTALL FRONT BUMPER (See Pub. No. RM734E BO section)

4. FILL WITH ENGINE COOLANT

5. INSTALL COOLING FAN

6. START ENGINE AND CHECK FOR COOLANT LEAKS