

AIR CONDITIONER UNIT

AC2IE-01

ON-VEHICLE INSPECTION

INSPECT FOR LEAKAGE OF REFRIGERANT

- (a) Remove the glove compartment door ([See page BO-80](#)).
- (b) Remove the blower unit.
- (c) Using a gas leak detector, check for leakage of refrigerant.

If there is leakage, check the tightening torque at the joints or check the evaporator, expansion valve, A/C tube and O-ring.