



DISASSEMBLY**COMBINATION METER COVER:**


- (a) Remove the 8 screws.
- (b) Remove the combination meter cover.



- (c) Remove the meter circuit plate.



- (d) Remove the 6 clips and the meter glass.



- (e) Remove the 4 clips and the meter plate.

