




INSPECTION

INSPECT FUEL TANK AND LINE

- Check the fuel lines for cracks or leakage, and all connections for deformation.
- Check the fuel tank for deformation, cracks fuel leakage or tank band looseness.
- Check the filter neck for damage or fuel leakage.
- Hose and tube connections are as shown in the illustration.

If a problem is found, repair or replace the part as necessary.

