

INSTALLATION

Installation is in the reverse order of removal ([See page BR-11](#)).

HINT:

- Before installation, adjust length of brake booster push rod ([See page BR-17](#) or [BR-22](#)).
- After installation, fill the brake reservoir with brake fluid, bleed the brake system ([See page BR-4](#)), and check for leaks.
- Check and adjust brake pedal ([See page BR-6](#)).