



MANUAL TRANSAXLE UNIT

COMPONENTS

MX09X-02



D07390



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

* For use with SST

N

D10558