


MANUAL TRANSAXLE ASSEMBLY

COMPONENTS


MX01F-03




N·m (kgf·cm, ft·lbf) : Specified torque

γ ◆ Non-reusable part

D06023





D06025