

INSPECTION

1. VEHICLE NOT INVOLVED IN COLLISION

Do a diagnostic system check ([See page DI-118](#)).

2. VEHICLE INVOLVED IN COLLISION AND AIRBAG IS NOT DEPLOYED

Do a diagnostic system check ([See page DI-118](#)).

3. VEHICLE INVOLVED IN COLLISION AND AIRBAG IS DEPLOYED

Replace the airbag sensor assembly ([See page DI-118](#)).