



















AUTOMATIC TRANSAXLE










SST (Special Service Tools)






PP2GY-01

	09308-00010 Oil Seal Puller	
	(09316-00010) Replacer Pipe <mk2>	
	09350-32014 TOYOTA Automatic Transmission Tool Set	
	(09351-32070) No.2 Piston Spring Compressor	
	(09351-32090) Oil Seal Remover & Replacer	
	(09351-32120) Overdrive Bearing Replacer	
	(09351-32140) Oil Seal Replacer	
	(09351-32150) Oil Seal Replacer	
	09387-00020 Direct Clutch Wrench	
	09387-00030 Counter Drive Gear Holding Tool	
	09387-00040 Bearing Puller Assembly	
	(09387-01010) Claw No.1	







	(09387-01020) Claw No.2	
	(09387-01030) Pin	
	(09387-01040) Bearing Puller Body	
	09387-00050 Under Drive Gear Puller	
	09387-00060 Second Brake Wrench	
	09387-00070 First & Reverse Brake Wrench	
	09387-00080 Counter Drive Gear Nut Wrench	
	09506-35010 Differential Drive Pinion Rear Bearing Replacer	
	09514-35011 Rear Wheel Bearing Puller	
	09564-16020 Drive Pinion Lock Nut Wrench	
	09564-32011 Differential Preload Adaptor	
	09649-17010 Steering Knuckle Tool	
	09930-00010 Drive Shaft Nut Chisel	

PREPARATION - AUTOMATIC TRANSAXLE

	(09931-00010) Handle	
	(09931-00020) Nut Chisel	
	09950-00020 Bearing Remover	
	09950-00030 Bearing Remover Attachment	
	09950-40011 Puller B Set	
	(09951-04010) Hanger 150	
	(09952-04010) Slide Arm	
	(09953-04020) Center Bolt 150	
	(09953-04030) Center Bolt 200	
	(09954-04010) Arm 25	
	(09955-04011) Claw No.1	
	(09955-04061) Claw No.6	
	(09957-04010) Attachment	

	(09958-04011) Holder	
	09950-60010 Replacer Set	
	(09951-00250) Replacer 25	
	(09951-00320) Replacer 32	
	(09951-00340) Replacer 34	
	(09951-00400) Replacer 40	
	(09951-00440) Replacer 44	
	(09951-00450) Replacer 45	
	(09951-00600) Replacer 60	
	(09951-00890) Replacer 89	
	09950-60020 Replacer Set No.2	
	(09951-00680) Replacer 68	
	(09951-00720) Replacer 72	

PREPARATION - AUTOMATIC TRANSAXLE

	(09951-00810) Replacer 81	
	(09951-00890) Replacer 89	
	09950-70010 Handle Set	
	(09951-07100) Handle 100	
	(09951-07150) Handle 150	
	(09955-04011) Claw No.1	
	(09955-04061) Claw No.6	
	(09958-04011) Holder	