

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
Input turbine speed sensor x Transaxle case		11	110	8
Union x Transaxle case		27	275	20
Manual valve lever shaft x Control lever		6.9	70	61 in.·lbf
Manual valve lever shaft x Park/neutral position switch		6.9	70	61 in.·lbf
Park/neutral position switch x Transaxle case		5.4	55	48 in.·lbf
Screw plug		7.4	75	65 in.·lbf
Drain plug		17	175	13
Transaxle case x Oil pan		7.8	80	71 in.·lbf
Oil strainer x Valve body assembly		11	110	8
ATF temperature sensor lock plate x Valve body assembly		6.6	66	58 in.·lbf
Transaxle wire x Transaxle case		5.4	55	48 in.·lbf
Valve body assembly x Transaxle case		11	110	8
Detent spring x Valve body assembly	Bolt A	20	205	15
	Bolt B	12	120	9
Parking lock pawl bracket x Transaxle case		20	205	15
Transaxle housing x Transaxle case	Bolt A	29	300	21
	Bolt B	29	300	21
	Bolt C	22	220	16
Transaxle housing x Oil separator		9.8	100	87 in.·lbf
Transaxle rear cover x Transaxle case	Bolt A	18.6	190	14
	Other bolt	24.5	250	18
Oil pump x Transaxle case		22	220	16
Counter drive gear lock nut		280	2,855	207
Oil pump body x Stator shaft		9.8	100	7
Valve body assembly x Shift solenoid valve	Bolt A	11	110	8
	Bolt B	6.6	67	58 in.·lbf
Valve body assembly x Shift solenoid valve DSL, S4, SL2		11	110	8
Pressure relief ball cover x Upper valve body		11	110	8
Upper valve body x Lower valve body		11	110	8
Differential case x Differential ring gear		96	980	71
Counter gear speed sensor x Transaxle case		11	110	8
No. 1 transaxle apply pipe clamp x Transaxle housing		9.8	100	87 in.·lbf
Apply pipe clamp x Transaxle case		5.4	55	48 in.·lbf
Parking lock pawl shaft clamp x Transaxle case		9.8	100	87 in.·lbf
U/D planetary gear x Nut		280	2,855	207
Upper valve body x Cover	Bolt A	11	110	8
	Bolt B	11	110	8
	Bolt C	6.6	67	58 in.·lbf
	Bolt D	6.6	67	58 in.·lbf
Pressure relief valve spring seat x Lower valve body		6.6	67	58 in.·lbf