


HEADLIGHT BEAM LEVEL CONTROL SYSTEM LOCATION


BE2FU-01

w/ HID:






Headlight Units

- Headlight Leveling Actuator




Height Control Sensor




w/ HID:**RHD:**

w/o HID:



Headlight Units

- Headlight Leveling Actuator



Ignition Switch

Headlight Beam Level
Control Switch

P