

PRE-CHECK

FAIL SAFE FUNCTION

Headlight Beam Level Control Computer

Trouble Area	Condition	Recovery Condition	Indicator light comes on.
Headlight Leveling ECU	High voltage	Normal voltage	○
Headlight Leveling ECU	Low voltage	Normal voltage	–
Vehicle speed sensor	Vehicle speed is detected to be over 180 km/h	Under 180 km/h	–
Height control sensor	Height signal malfunction	Normal signal is detected for 5 secs.	–
Height control sensor	Height control sensor power source voltage malfunction	Normal signal is detected for 5 secs.	○
Height control sensor	Open or short in height control sensor source circuit	Normal signal is detected for 5 secs.	○
Headlight Leveling ECU	Watchdock detection	Headlight ECU reset is released	○