

INSTALLATION

INSTALL FRONT SEAT

- (a) Mount the front seat to the vehicle.

NOTICE:

Be careful not to damage the body.

- (b) Connect the connectors.
- (c) Slide the front seat to the most front position.
- (d) Tighten the bolts on the rear side temporarily, starting from the bolt on the inner side tighten them completely.

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

- (e) Slide the seat to the most rear position to install the bolts on the front side.

Torque: 37 N·m (375 kgf·cm, 27 ft·lbf)

- (f) Install the seat track covers.