


ANTI-LOCK BRAKE SYSTEM WITH ELECTRONIC BRAKE FORCE DISTRIBUTION (EBD)

HOW TO PROCEED WITH TROUBLESHOOTING

DI6M7-04

Troubleshoot in accordance with the procedure on the following pages.



Fail safe function:

When a failure occurs in the ABS system, the ABS warning light comes on and the ABS operation is prohibited. In addition to this, when the failure which disables the EBD operation occurs, the brake warning light comes on as well and the EBD operation is prohibited.