



## DESCRIPTION


### PARTS LOCATION




## ELECTRICAL WIRING DIAGRAM



## REAR HEATER



## DAMPERS POSITION



| A/C control lever         | A/C control lever position | Dampers position          | Air flow vents |      |      |      |
|---------------------------|----------------------------|---------------------------|----------------|------|------|------|
|                           |                            |                           | FACE           |      | FOOT | D EF |
|                           |                            |                           | Center         | Side |      |      |
| Air Inlet Control Lever   | Fresh                      | ①                         | /              | /    | /    | /    |
|                           | Recirc                     | ②                         |                |      |      |      |
| Temperature Control Lever | Warm                       | ⑤<br>↕<br>④ ⑦<br>↕<br>③ ⑥ | /              | /    | /    | /    |
|                           | Cool                       |                           |                |      |      |      |
| Mode Control Lever        | Def.                       | ⑪ ⑫ ⑰ ⑳                   |                | ○    |      | ○    |
|                           | Foot/Def.                  | ⑩ ⑰ ⑳ ⑬                   |                | ○    | ○    | ○    |
|                           | Foot                       | ⑨ ⑬ ⑰ ⑳                   |                | ○    | ○    | ○    |
|                           | Bi-Level                   | ⑧ ⑬ ⑯ ⑱                   | ○              | ○    | ○    |      |
|                           | Face                       | ⑧ ⑫ ⑮ ⑱                   | ○              | ○    |      |      |

The size of circle (○) indicates the proportion of the air flow volume.