











AUTOMATIC TRANSMISSION (A340E, A340F)

SST (Special Service Tools)

PP1YE-01

	09032-00100 Oil Pan Seal Cutter	Valve body assembly
	09308-00010 Oil Seal Puller	Extension housing oil seal
	09309-37010 Transmission Bearing Replacer	Extension housing oil seal
	09350-30020 TOYOTA Automatic Transmission Tool Set	
	(09351-32010) One-way Clutch Test Tool	Torque converter clutch and drive plate
	(09351-32020) Stator Stopper	Torque converter clutch and drive plate
	09950-60010 Replacer Set	
	(09951-00350) Replacer 35	Extension housing oil seal
	09950-70010 Handle Set	
	(09951-07100) Handle 100	Extension housing oil seal