



# STARTER COMPONENTS


ST01J-02





## Magnetic Switch Assembly

S05731



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

S02425

Z19063