



Trailer Towing (Access/Standard Cab)





Trailer Towing (Access/Standard Cab)

: Parts Location

| Code | See Page | Code | See Page | Code | See Page |
|------|-------------|------|-------------|------|-------------|
| B3 | 60 | J18 | 57 (2UZ-FE) | P1 | 57 (2UZ-FE) |
| D8 | 61 | | 59 (1GR-FE) | | 59 (1GR-FE) |
| J1 | 57 (2UZ-FE) | J23 | A | S4 | A |
| | 59 (1GR-FE) | J24 | B | S31 | |
| J2 | 57 (2UZ-FE) | J26 | A | T5 | |
| | 59 (1GR-FE) | J27 | B | | |
| J3 | 62 | J28 | A | T6 | A |
| J8 | 62 | J29 | B | | B |
| J9 | 62 | J63 | 57 (2UZ-FE) | | 64 (*3) |
| J10 | 62 | | 59 (1GR-FE) | | 65 (*4) |
| J12 | 62 | O5 | 62 | T9 | 63 |

: Relay Blocks

| Code | See Page | Relay Blocks (Relay Block Location) |
|------|----------|---|
| 2 | 24 | Engine Room R/B (Engine Compartment Left) |

: Junction Block and Wire Harness Connector

| Code | See Page | Junction Block and Wire Harness (Connector Location) |
|------|----------|--|
| 1D | 26 (*1) | Cowl Wire and Driver Side J/B (Lower Finish Panel) |
| | 30 (*2) | |
| 1E | 26 (*1) | Engine Room Main Wire and Driver Side J/B (Lower Finish Panel) |
| | 30 (*2) | |
| 1F | 26 (*1) | Cowl Wire and Driver Side J/B (Lower Finish Panel) |
| | 30 (*2) | |
| 1G | 26 (*1) | |
| | 30 (*2) | |
| 1J | 26 (*1) | |
| | 30 (*2) | |

: Connector Joining Wire Harness and Wire Harness

| Code | See Page | Joining Wire Harness and Wire Harness (Connector Location) |
|------|----------|---|
| IA9 | 82 | Engine Room Main Wire and Cowl Wire (Left Kick Panel) |
| IE1 | 83 | Engine Wire and Cowl Wire (Right Side of Instrument Panel) |
| BB5 | 84 (*3) | Frame Wire and Cowl Wire (Under the Driver's Seat) |
| | 85 (*4) | |
| BK1 | 84 (*3) | Frame Wire and Frame No.3 Wire (Near the License Plate Light) |
| | 85 (*4) | |
| BK2 | 84 (*3) | |
| | 85 (*4) | |

: Ground Points

| Code | See Page | Ground Points Location |
|------|-------------|---|
| EA | 80 (2UZ-FE) | Front Left Fender |
| | 81 (1GR-FE) | |
| IE | 82 | Left Kick Panel |
| IF | | |
| BL | 84 (*3) | Surrounding of the Front of the Fuel Tank |
| | 85 (*4) | |

* 1 : w/o Daytime Running Light

* 2 : w/ Daytime Running Light

* 3 : Access Cab

* 4 : Standard Cab

* 5 : Access Cab Captain Seat

* 6 : Access Cab Separate Seat

* 7 : Standard Cab Bench Seat

