



Access Cab, Standard Cab:**Double Cab:**

N


I11192
I27161

I27950

REASSEMBLY

1. INSTALL LENS

Install the lens.


Access Cab, Standard Cab:

N

I11191

2. Access cab, Standard cab: INSTALL INTEGRATION CIRCUIT

- (a) Connect the 2 connectors.
- (b) Install the circuit.


Double Cab:

N

I27162

3. Double cab: INSTALL INTEGRATION CIRCUIT

- (a) Install the circuit.
- (b) Install the 2 screws.


Access Cab, Standard Cab:

N

I11190


4. Access cab, Standard cab: INSTALL HEATER CONTROL HOUSING

- (a) Connect the connector.
- (b) Install the heater control housing.
- (c) Install the 5 screws.




**5. Double cab:
INSTALL HEATER CONTROL HOUSING**

- (a) Install the heater control housing.
- (b) Install the 6 screws.



6. INSTALL BULBS

- (a) Access cab, standard cab:
Install the 5 bulbs.
- (b) Double cab:
Install the 6 bulbs.



**7. Access cab, Standard cab:
INSTALL AIRBAG INDICATOR CIRCUIT**

- (a) Connect the connector.
- (b) Install the circuit.