


# POWER SEAT CONTROL SYSTEM

## LOCATION

BE17F-07

Double Cab:  
Instrument Panel J/B  
● PWR SEAT Fuse



Except Double Cab:  
Driver Side J/B  
● POWER Fuse

### Driver's Seat

