

## INSTALLATION

Installation is in the reverse order of removal (see page [BO-111](#)).

**CONNECT CABLE TO NEGATIVE BATTERY TERMINAL**