


OUTPUT SHAFT COMPONENTS

MTOHY-01



◆ Non-reusable part

➡ Apply gear oil

D14074