

INSPECTION

HINT:

The SRS wire harness is integrated with the cowl wire harness assembly. The SRS wire harness are encased in a yellow corrugated tube and all the connectors in the system except the seat position airbag sensor connector and occupant classification ECU connectors, are colored yellow.

1. VEHICLE NOT INVOLVED IN A COLLISION

Perform a diagnostic system check (see page [DI-1851](#)).

2. VEHICLE INVOLVED IN A COLLISION

- (a) Perform a diagnostic system check (see page [DI-1851](#)).
- (b) Check breaks in all wires of the SRS wire harness, and exposed conductors.
- (c) Check if the SRS wire harness connectors are cracked or chipped.