



VVT SENSOR COMPONENTS

SF1XX-01





N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part