
Manifold absolute pressure (MAP) sensor
Crank angle sensor
Engine coolant temperature sensor
Intake air temperature sensor
Various sensors
Reading input signals
Determining driving modes
Driving mode judgment data
Basic valve opening duration data
Data for correction coefficient, such as intake air temperature, engine coolant temperature sensor
Setting injector actuation timing
Setting basic injector actuation duration
Injector actuation duration correction
Injector actuation duration correction
Injector
AK305467AB