
Air flow sensor
Intake air temperature sensor
Engine coolant temperature sensor
Accelerator pedal position sensor (main)
Throttle position sensor (sub)
Crank angle sensor
Camshaft position sensor
Detonation sensor
Oxygen sensor (front)
Oxygen sensor (rear)
Clutch switch
Ignition switch-IG
Ignition switch-ST
Power supply
Alternator FR terminal
Alternator L terminal
Throttle valve contorol servo power supply
Throttle position sensor (main)
Accelerator pedal position sensor (sub)
Engine-ECU
Barometric pressure sensor
[1] Fuel injection control
[2] Throttle valve opening control and idle speed control
[3] Ignition timing control
[4] MIVEC (Mitsubishi Innovative Valve timing Electronic Control system)
[5] Power supply control (Power supply to sensor, actuator)
[6] Fuel pump relay control
[7] Oxygen sensor heater control
[8] Waste gate control
[9] Fuel pressure control
[10] A/C compressor relay control
[11] Alternator control
[12] Starter relay control
[13] Purge control
[14] Diagnostic output
[15] RAM data transmission
No. 1 injector
No. 2 injector
No. 3 injector
No. 4 injector
No. 1 ignition coil
No. 2 ignition coil
No. 3 ignition coil
No. 4 ignition coil
Engine control relay
Starter relay
Fuel pump relay
Throttle valve control servo relay
Oxygen sensor heater (front)
Oxygen sensor heater (rear)
Waste gate solenoid valve
Fuel pressure control solenoid valve
A/C compressor relay
Oil control valve (for MIVEC)
Purge control solenoid valve
Alternator G terminal
Throttle valve control servo (DC motor)

AK801569 AB