

DTC	P0604	Internal Control Module Random Access Memory (RAM) Error
DTC	P0606	ECM / PCM Processor
DTC	P0607	Control Module Performance
DTC	P0657	Actuator Supply Voltage Circuit / Open

MONITOR DESCRIPTION

ES The ECM continuously monitors its internal memory status, internal circuits, and output signals to the throttle actuator. This self-check ensures that the ECM is functioning properly. If any malfunction is detected, the ECM will set the appropriate DTC and illuminate the MIL.

The ECM memory status is diagnosed by internal "mirroring" of the main CPU and the sub CPU to detect random access memory (RAM) errors. The 2 CPUs also perform continuous mutual monitoring. The ECM sets a DTC if: 1) outputs from the 2 CPUs are different and deviate from the standards, 2) the signals to the throttle actuator deviate from the standards, 3) a malfunction is found in the throttle actuator supply voltage, and 4) any other ECM malfunction is found.

DTC No.	DTC Detection Condition	Trouble Area
P0604 P0606 P0607 P0657	ECM internal error	ECM

MONITOR STRATEGY

Related DTCs	P0604: RAM Error P0606: CPU Malfunction P0607: ECM Range Check P0657: ETCS Power Supply
Required sensors / components (Main)	ECM
Required sensors / components (Related)	-
Frequency of operation	Continuous
Duration	Within 1 second
MIL operation	Immediate
Sequence operation	None

TYPICAL ENABLING CONDITIONS

The monitor will run whenever these DTCs are not present	None
--	------

TYPICAL MALFUNCTION THRESHOLDS

RAM Error:

RAM	RAM check failure
-----	-------------------

CPU Malfunction:

Either of the following conditions is met:	Condition 1 or 2
1. Difference between TP of main CPU and TP of sub CPU	0.3 V or more
2. Difference between APP of main CPU and APP of sub CPU	0.3 V or more

ECM Range Check:

Either of the following conditions is met:	Condition 1 or 2
1. All of the following conditions are met:	Condition (a), (b) and (c)
(a) CPU reset	1 time or more
(b) Difference between TP and APP learning values	0.4 V or more
(c) Electronic throttle actuator	OFF
2. CPU reset	2 times or more

ETCS Power Supply:

ETCS power supply when ignition switch is turned from OFF to ON	7 V or more
---	-------------

HINT:

Read freeze frame data using the intelligent tester or the OBD II scan tool. The ECM records vehicle and driving condition information as freeze frame data the moment a DTC is stored. When troubleshooting, freeze frame data can help determine if the vehicle was running or stopped, if the engine was warmed up or not, if the air-fuel ratio was lean or rich, and other data from the time the malfunction occurred.

ES

1 CHECK OTHER DTC OUTPUT (IN ADDITION TO DTC P0604/P0606/P0607/P0657)

(a) Check for DTCs.

OK:

DTC P0604, P0606, P0607 or P0657 is not output.

 **GO TO DTC CHART**
A**REPLACE ECM**